

PHONE BOOTH CAMERA HOUSING

INSTALLATION GUIDE

- STEP 1** Set out the booth shell, Ring camera, white sleeve, and red base.
- STEP 2** Slide the Ring camera into the white sleeve; align all camera openings.
- STEP 3** Seat the camera-and-sleeve assembly firmly and evenly on the red base.
- STEP 4** Lower the phone booth shell over the assembly with the camera facing front.
- STEP 5** Press the booth fully onto the base; confirm the lens and sensors are clear.

FINAL CHECK: Verify the live camera view before placing the finished booth in service.

POWER CORD: Route it through the slot in the lower back of the housing before seating the booth on the base.



1 PARTS

Booth shell, camera, sleeve, and base



2 ALIGN CAMERA

Match the camera face and openings



3 SEAT ON BASE

Keep the assembly centered and level



4 FINISHED ASSEMBLY

Lens and sensors remain clear



MORE DESIGNS + CUSTOM BUILDS

Visit www.TMLFunCreations.com

Use code TML10 for 10% off



Tml Fun Creations
From Mind to Matter