

Ring Camera – Factory Base Removal

IMPORTANT: The factory mounting base must be removed before installing the camera into a planter-style housing.

STEP 1: Place the Ring camera on its side with the factory mounting base facing up.

STEP 2: Using a Phillips screwdriver, loosen the center screw. Do not fully remove the screw.

STEP 3: Rotate the mounting base counter-clockwise to unlock it from the camera.

STEP 4: Pull the base straight out from the camera body. Set the base aside.



NOTE: This base is not used with TML Fun Creations planter housings.