

TML Fun Creations

Ring Outdoor Cam 4K Pro - Woven Planter Cover

TML-198 | Installation Instructions

1. Remove the camera base.

Disconnect power. Detach the factory base as shown and set it aside.

2. Route the power cord.

Connect the cord to the camera and guide it through the rear cord opening.

3. Insert the camera.

Remove the top insert. Gently lower the camera onto the internal support, with the lens facing the front opening. Do not pinch the cord.

4. Align the lens.

Center the lens in the circular opening and make sure its view is clear.

5. Replace the top insert.

Fit the planter topper or faux plant assembly into place. Keep foliage clear of the camera opening.

6. Check the camera view.

Reconnect power. Open Live View in the Ring app and adjust the housing position as needed.



Remove the camera base before installing



Cutaway view of housing—for illustration only



Lens aligned



Topper and camera

Cutaway photo note: The second photo shows a cut view of the housing to illustrate how the camera sits inside. Your housing remains intact - no cutting is required.



Example camera view after installation

Camera not included.

Questions? Contact TML Fun Creations at www.tmlfuncreations.com